


PARTS MANUAL

FOR

MCC-4040100
with hammer flails

PRINTED ON 28 SEP 2023


4002270 - FRAME ASSEMBLY



Ref	Part No	Description	QTY
1	4000187	CASING	1
2	4000197	SKID -LH	1
3	4000200	SKID -RH	1
4	4002278	BELT COVER	1
5	4000758	WASHER	28
6	7315594	BOLT	4
7	4000416	AUTOGRIP NUT	4
8	4000209	SCREW	2
9	4000756	LOCK NUT	8
10	4000184	BRACKET	2
11	4000183	RUBBER SUPPORT	2
12	4000210	BOLT	6
13	4000214	SCREW	4
14	4001425	NUT	4
15	4001424	NUT	4
16	4001311	FRONT HOOD	1
17	4000185	RAM BRACKET	1
18	4000182	STIRRUP	1
19	4001537	WASHER	4

Ref	Part No	Description	QTY
20	4000213	SCREW	2
21	4001191	LOCK NUT	2
22	4000759	WASHER	2
23	4000760	WASHER	2
24	4000212	SCREW	2
25	4000610	WASHER	2
26	4000252	SCREW	2
27	4000224	GREASER	1
28	1335246.01	MCCONNEL SERIAL PLATE - ITALY	1
29	7103230	RIVET	4


4002271 - MOUNTING ASSEMBLY



Ref	Part No	Description	QTY
1	4000224	GREASER	1
2	4002279	BRACKET	1
3	4000749	SPRING	1
4	4000205	BOLT	1
5	4000339	NOW USE 4000206	1
6	4000218	NUT	4
7	4000215	SCREW	2
8	4000253	WASHER	1
9	4000757	LOCK NUT	1
10	4000380	SCREW	2
11	4001288	NOW USE 4000761	2
12	4000661	PLATE	1
13	4002280	MOUNTING JOINT	1
14	4001393	LARGE WASHER	1
15	4001538	WASHER	1
16	7315892	SCREW	1
17	4001394	ROLL PIN	1
18	4000357	WASHER	4
19	4000212	SCREW	4


Ref	Part No	Description	QTY
20	4000628	MOUNTING BRACKET ASSEMBLY	1
21	4002281	BUSH	2

4002272 - RUBBER FLAP KIT




Ref	Part No	Description	QTY
1	4000189	RUBBER FLAP	1
2	4000188	STRIP	2
3	4001427	REINFORCEMENT	1
4	4001258	FRONT FLAP	1
5	4000445	SCREW	18

4002273 - REAR ROLLER ASSEMBLY





Ref	Part No	Description	QTY
1	4000194	ROLLER - HVY/LGT ROTORS	1
2	4002282	FLANGED BEARING	1
3	4000196	BRACKET - ROLLER LH	1
4	4000212	SCREW	4
5	4004008	SETSCREW	4
6	4000758	WASHER	8
7	4000023	CIRCLIP	1
8	4001422	WASHER	4
9	4000760	WASHER	4
10	4000416	AUTOGRIP NUT	4
11	4001882	FLANGED BEARING	1
12	4000195	BRACKET - ROLLER RH	1
13	4002283	CIRCLIP	1



4002274 - DRIVE ASSEMBLY




Ref	Part No	Description	QTY
1	4000231	PULLEY	1
2	4000233	BELT - TOOTHED ON F/HEAD	3
3	4000208	SCREW	1
4	4000416	AUTOGRIP NUT	2
5	4000227	TAPERLOCK	1
6	4000217	SCREW	4
7	4000220	FLANGED NUT	2
8	4000199	PLATE	1
9	4000232	PULLEY	1
10	4000531	LOCK	1
11	4001381	WASHER	2
12	4002284	MOTOR PLATE	1
13	4002285	SCREW	2



Part No. 4000255
Y-FLAILS KIT (6mm)
(Single Station)




Part No. 4001092
HAMMER FLAIL KIT
(Single Station)



Part No. 4000256
HAMMER FLAIL KIT
(Single Station)

REF.	QTY.	PART No.	DESCRIPTION
ROTORS & FLAILS ASSEMBLY			
1	1	4000190	1.3M ROTOR (Y-FLAILS TYPE)
2	2	4000241	STEEL BUSHING
3	2	4000242	Y-FLAIL (6mm)
4	1	4000243	HAMMER FLAIL (Early Type) ► 06/14
5	1	4000244	1.3M ROTOR (HAMMER FLAIL TYPE)
6	2	4000245	BUSHING
7	1	4000703	1.3M ROTOR C/W Y-FLAILS
8	1	4000704	1.3M ROTOR C/W HAMMER FLAILS
9	2	4000246	SCREW
10	1	4000247	SCREW
11	2	4000248	AUTOGRIP NUT
12	1	4000249	AUTOGRIP NUT
13	1	4001091	HAMMER FLAIL (Later type) 06/14 ►
SINGLE STATION FLAIL KITS			
	1	4000255	Y-FLAILS KIT (6mm Flail)
	1	4000256	HAMMER FLAIL KIT (Flail 4000243) ► 06/14
	1	4001092	HAMMER FLAIL KIT (Flail 4001091) 06/14 ►
22 STATION FLAIL KIT			
	1	4000268	Y-FLAILS KIT (6mm Flail)


4002276 - HYDRAULIC INSTALLATION



Ref	Part No	Description	QTY
1	4000186	RAM	1
2	4001297	SEAL KIT	1
3	4001431	CONNECTOR	1
4	4002288	ADAPTOR	1
5	4000748	CONNECTOR	3
6	4000229	MOTOR	1
7	4000716	SEAL KIT	1
8	4002289	HOSE	1
9	4002290	HOSE	1
10	4002291	HOSE	1
11	4002292	HOSE SLEEVE	1
12	4002293	HOSE SLEEVE	1
13	4002294	HOSE	1
14	4002295	HOSE	1
15	4000587	CONNECTOR	2
16	4002209	COUPLING	1
17	4002208	COUPLING	1

Ref	Part No	Description	QTY
18	4002206	QR COUPLING	1
19	4002205	QR COUPLING	1
20	4002296	COUPLING	1
21	7315797	CONNECTOR	3

4002277 - DECAL KIT



Ref	Part No	Description	QTY
1	4002297	DECAL - GREASE (4 HOURS)	2
2	4000891	DECAL	2
3	4000769	DECAL KIT	5
4	4001432	SAFETY DECALS	1
5	4000771	DECAL	1

